Tapware Installation Guide

Thank you for choosing Sergio Tapware

Important

- All Sergio Tapware is to be installed by a licensed plumber.
- All Sergio Tapware must have a in-line filter to protect the ceramic cartridge failure to do so may void claims of warranty.

Pressure & Temperature Limits

- Recommended pressure: maximum pressure 1200kpa for all Sergio Tapware minimum pressure of 150kpa (for YOURKE)
- Maximum water temperature of 80°C

Equal or Unequal Pressure

- For equal pressures, discard the adjustable flow regulator enclosed.
- For unequal pressure, please attach the adjustable flow regulator to the cold line and set regulator to desired flow rate.

Installation

Flush all pipework to remove sediment before installing tap.

Finished order of assembled items:

- a) Tap
- b) Dress Ring
- c) Rubber O-Ring

Benchtop

- d) Rubber washer
- e) Brass Nut and/or Metal Washer

Please Check

Ensure the tap is installed securely in the benchtop. Add under bench strengthening if required. Pull lever open (water flows), depress lever (water stops), turn lever left and right to check hot and cold water operates as the hot/cold indicator illustrates.

Care & Maintainance

The Sergio product you have chosen is designed to provide many years of reliable service. However the finish on all plumbing products requires care to retain its life. The everyday cleaning procedure is as follows: Rinse all traces of soap thoroughly. Wipe and gently buff with a soft cloth. Do not use abrasive cleaners. As expected this tap will show signs of general wear over time. Regularly check to see if fixings are tight. If the tap become loose, immediately tighten to prevent damage.

